

Motosierra


MS-50





**Motosierra**Modelo: **MS-50****Despiece**

NO.	PART NUMBER	QTY	DESCRIPTION	NO.	PART NUMBER	QTY	DESCRIPTION
1	YD50.01.02-1	1	CYLINDER	50	YD45.01.00-26	1	SPROCKET
2	89.GB/T6170	2	NUT M5	51	YD45.01.00.06-00	1	WORM
3	89.GB/T93	17	WASHER 5	52	YD45.01.00-15	1	COVER PLATE
4	89.GB/T971	13	WASHER 5	53	YD45.01.00.09-00	1	OIL SEAL 15×28×4.5
5	YD45.01.09-1	1	MUFFLER COVER PLATE	54	89.GB/T276	2	BEARING 6202 D 15X35X11
6	YD50.01.09.01-00B	1	MUFFLER BODY	55	YD45.01.00-8	1	CUSHION BLOCK
7	YD45.01.00-2	1	MUFFLER SEALING PLATE	56	YD45.01.00-7	1	THROTTLE LEVER BRACKET
8	YD45.01.00-24	2	MUFFLER CONNECTING SCREW	57	YD45.01.00.03-00	1	CHOKE ROD
9	89.M38105X20	6	SCREW M5×20	58	YD45.01.00-11	1	RIGHT SHOCK BLOCK
10	YD45.01.11.04-00	1	SPARK PLUG LD L8RTF	59	YD45.01.00.07-00	3	CUSHION SOCKET
11	YD50.01.02.03	1	SPRING	60	YD45.01.00.01-00	1	AIR INTAKE TUBE SUPPORT
12	YD50.01.02-2	1	AIR INTAKE TUBE	61	YD45.01.00-4	1	TIE PLATE
13	89.M45135X12	2	SCREW M5×12	62	YD45.01.00-3	1	AIR INTAKE SUPPORT SEAL
14	YD45.01.00-17	1	RETAINER	63	YD45.01.00-14	1	AIR INTAKE TUBE FLANGE
15	YD45.01.00-1	1	CYLINDER SEALING PLATE	64	YD45.01.06-00	1	CARBURETOR
16	YD50.01.03-2	2	PISTON RING	65	YD45.01.00.02-1	1	AIR INTAKE SOCKET
17	YD50.01.03.03-00	1	PISTON	66	YD45.01.08-00	1	AIR FILTER
18	YD45.01.03-4	2	PISTON PIN CIRCLIP	67	89.GB/T899	1	2-SCREW BOLT M5×30
19	YD50.01.03-3	1	PISTON PIN	68	YD45.01.00-5	1	CUSHION
20	YD45.01.03-5	2	NEEDLE BEARING RING	69	89.M45695X50	2	SCREW M5×50
21	YD45.01.03.01-00	1	CRANKSHAFT ASSY	70	YD45.01.01.02-1	1	RIGHT CASE
22	YD45.01.03.02-00	1	NEEDLE BEARING 11×15×12.5	71	YD45.01.00-6	1	DUST PLATE
23	89.GB/T1099	1	SEMICIRCULAR KEY 3×3.5×10	72	89.GB/T11925X10	3	PIN 5×10
24	YD45.00.00-4	1	CONICAL SPREADER SPRING	73	YD45.01.11-2	1	GROUND STRIP
25	YD45.00.00-3	1	CONICAL SPREADER BASE	74	YD45.01.11.03-00	1	FLAMEOUT SWITCH
26	89.GB/T845	4	TAPPING SCREW ST4.8X16	75	YD45.01.11-1	1	FLAMEOUT SWITCH SOCKET
27	YD45.00.00.01-00	1	CHAIN CATCHER	76	YD45.01.00-10	1	LEFT SHOCK BLOCK
28	89.GB/T2672M516	1	SCREW M5×16	77	89.M45775X25	5	SCREW M5×25
29	YD45.01.01.02-2	1	AERATION JET	78	YD45.01.00-20	1	OIL SHIELD
30	YD45.01.01.02-3	1	AERATION JET CIRCLIP	79	89.M38434	2	WASHER 4
31	YD45.01.00-22	1	SPONGE TRANSITION BLOCK	80	89.M45794X8	2	SCREW M4×8
32	YD45.01.00-21	1	SPIKE BUMPER	81	89.M38394X10	4	SCREW M4×10
33	89.M45335X10	5	SCREW M5×10	82	YD45.01.10-00A	1	FLYWHEEL ASSEMBLY
34	YD45.01.00.04-2	1	OIL FILTER SCREEN	83	89.GB/T61772	1	NUT M8×1
35	YD45.01.00.04-1	1	OIL FILTER	84	YD45.01.00.05-00	1	CAP ASSEMBLY
36	YD45.01.00-12	1	OIL TUBE	85	YD45.01.00.05-3	1	PACKING WASHING 20X30X2
37	89.M38424X14	2	SCREW M4×14	86	YD38-3.03.02-2	1	ANTI-DROP PLATE
38	YD45.01.15-00	1	OIL PUMP	87	YD45.01.00.05-1	1	OIL COVER
39	YD45.01.00-23	1	SPONGE TRANSITION COIL	88	YD45.01.01.01-3	2	SUCTION TUBE CIRCLIP
40	YD45.01.00-13	1	NOZZLE	89	YD45.01.01.01-2	1	SUCTION TUBE 2.5×6×105
41	YD45.01.00-16	1	CHAIN GUIDE BLOCK	90	YD45.01.01.03-00	1	SUCTION JET
42	89.GB/T900	2	2-SCREW BOLT M8X26	91	YD45.01.01.01-1	1	LEFT CASE
43	YD45.01.13.01-00	1	CLUTCH	92	89.M459235	1	SHIELD RING 35
44	YD45.01.13.01-2	3	SHOE BLOCK	93	YD45.01.00.08-00	1	OIL SEAL 15X35X4.5
45	YD45.01.13.01-1	1	RETAINER	94	YD45.01.11.01-00	1	IGNITER
46	YD45.01.13.01-3	1	CLUTCH SPRING	95	YD45.01.11.02-00	1	EXTINCTION CONDUCTOR
47	YD45.01.00-19	1	CLUTCH ADJUSTING WASHER	96	YD45.00.00-9	2	DUST COVER
48	YD45.01.00.10-00	1	NEEDLE BEARING 12×15×14.5	97	YD45.01.01-1	1	CASE BODY SEAL
49	YD45.01.13-1	1	CLUTCH SHELL	98	YD45.01.00-18	1	DAMPER



**Motosierra**Modelo: **MS-50****Despiece**

NO.	PART NUMBER	QTY	DESCRIPTION	NO.	PART NUMBER	QTY	DESCRIPTION
1	YD45-5.04.00-00	1	RIGHT COVER ASSY	37	YD45.02.00-1	1	BOSSING
2	YD38-3.04.00-16	1	SCREW M5×40	38	YD45-5.02.00-00	1	STARTER ASSEMBLY
3	YD38-3.04.00-13	1	PIN GLAND 5×6.3×30	39	89.M503948X14	1	TAPPING SCREW ST4.8×14
4	YD38-3.04.00-12	1	HEAVY BROCK GLAND 6.3×9×17	40	89.GB/T96	1	WASHER 5
5	89.M38143X14	1	PIN 3×14	41	YD45.02.00-2	1	STARTER PLATE
6	YD45.04.00-19	1	TENSION BLOCK	42	YD45.02.00-5	1	START COIL SPRING
7	YD45.04.00-18	1	TIGHTENER SCREW	43	YD62.02.00-3	1	START HANDLE
8	YD45.04.00-11	1	TENSIONER COVER	44	YD45.02.00-7	1	START ROPE
9	89.M382142X95	4	TAPPING SCREW ST4.2X9.5	45	YD45-5.02.00-1	1	STARTER COVER
10	YD45-4.04.00-2	1	FRONT DAMPER	46	YD45.03.00-1	1	SHOCK RUBBER
11	YD38-3.04.00-8	1	BRAKE TORSION ROD SPRING	47	YD45.03.01-00A	1	BASE
12	89.M5012522012	1	WASHER 5.2×20×1.2	48	YD45.03.02-00	2	SHOCK RUBBER GLAND
13	89.GB/T61831	1	LOCK-NUT M5	49	YD50.00.00-9	2	SCREW
14	YD38-3.04.00-6	1	SPRING BASE	50	YD45.00-00-2	2	DUST COVER
15	YD38-3.04.00-5	1	FRONT GUARD SPRING	51	YD38-3.03.02-00	1	FUEL TANK-CAP ASSY
16	YD38-3.04.00-4	1	MAIN LEVEL	52	YD38-3.03.02-2	1	ANTI-DROP PLATE
17	YD38-3.04.00-3	1	SECONDARY PULL-ROD	53	YD38-3.03.02-3	1	PACKING WASHER 24×34×1.5
18	89.M25843X9	3	PIN 3X9	54	YD38-3.03.02-1	1	FUEL CAP
19	YD45.04.00-14	1	BRAKE CONTROL ROD	55	YD45.03.00-2	1	FUEL TUBE
20	YD45.04.00-9	1	BRAKE SPRING	56	YD45.03.00-15	1	FUEL TUBE CIRCLIP
21	YD45-4.04.00-9	1	BRAKE STRAP	57	YD45.03.03-00	1	FUEL FILTER ASSY
22	YD45-4.04.00-1	1	BRAKE SPRING COVER PLATE	58	YD45.03.04-00	1	BALANCER
23	YD45.04.00-20	1	TENSION BLOCK	59	YD38-3.03.00-3	1	BALANCER ROOT
24	YD45.01.00-16	1	CHAIN GUIDE BLOCK	60	YD45.01.00-25	1	THROTTLE ROD
25	YD45-5.04.01-00	1	RIGHT COVER	61	YD45.03.00-11	1	TRIGGER
26	YD45-4.04.00-7	1	DUST SHIELD	62	YD45.03.00-12	1	TRIGGER TORSION ROD SPRING
27	YD38-3.04.00-7	1	WEIGHT TORSION ROD SPRING	63	89.GB/T11926X22	1	PIN 6X22
28	YD38-3.04.02-00	1	HEAVY BLOCK	64	YD45.03.00-14	1	HANDLE COVER
29	YD45.04.00-10	1	2ND BRAKE SPRING	65	YD45.03.00-13	1	TRIGGER CONTROL RACK
30	89.GB/T6177.1	2	NUT M8	66	89.M456042X25	1	TAPPING SCREW ST4.2×25
31	YD45.05.01-00	1	AIR FILTER LOCK NUT	67	YD50.06.00-00	1	FRONT HANDLE ASSEMBLY
32	YD45.05.00-2	1	LOCK NUT WASHER 15×26×6	68	89.GB/T845	4	TAPPING SCREW ST4.8X16
33	YD45-5.05.00-1	1	AIR FILTER COVER	69	YD45-4.03.00-11	1	SCAVENGE NOZZLE
34	YD45.00.00-6	1	IDLE ADJUSTING GUIDE SET	70	YD45.03.00-17	1	PUMP TUBE
35	89.GB/T2672M516	9	SCREW M5×16	71	A38.0311.0100	1	PRIMER BULB
36	YD45-5.00.00-1	1	UPPER COVER PLATE				